



## **BLOW-OFF ASSEMBLY**

NOT TO SCALE

### NOTES:

1. SEE STD. DETAIL 701A FOR CONNECTION TO MAIN.
2. SET METER BOX FLUSH WITH SIDEWALK OR CURB ELEVATION IF LOCATED IN LAWN AREA.  
SET METER BOX APPROX 2-INCHES ABOVE FINISHED GRADE IF IN LANDSCAPING AREA.
3. INSTALL STD. MARKER POST IDENTIFYING BLOW-OFF LOCATION. (NOT SHOWN)
4. ANY ADDITIONAL FITTINGS FROM THE GATE VALVE TO THE MAIN SHALL BE BRASS.

APPROVED: SCOTT THOMASSON

REV. DATE: NOV. 01, 2005

WATER/WASTEWATER DIVISION



STANDARD DETAILS

**BLOW-OFF ASSEMBLY**

FILE SD707.DGN DRAWING NO. 707